

Spares List
(F40-300S)

| Ref. | Part Number | Description | Material | Qty. |
|------|----------------------|------------------------|---------------|------|
| 1 | F40L-94-01 | Locking Crescent | 304SSTT | 4 |
| 2 | F40L-12-01 | End Plate | ABS | 2 |
| 3 | F40L-58-01/90*5.3 | O-Ring | EPDM | 2 |
| 4 | F40L-59-01/19*2.65 | O-Ring | EPDM | 2 |
| 5 | F40L-02-01 | Strap | 304SST-Rubber | 2-3 |
| 6 | F40L-83-01 | Strap Screw | 304SST | 4-6 |
| 7 | F40L-03-01 | Saddle | Rubber | 2-3 |
| 8 | F40L-04-01 | Plug | ABS | 1 |
| 9 | F40L-53-01/23.6*3.55 | O-Ring | EPDM | 1 |
| 10 | F40L-88-01 | Locking Crescent Screw | 304SST | 4 |
| 11 | F40L-91-01 | Feed/Conc.Port | 316LSST | 2-4 |
| 12 | F40L-93-01/28*2.65 | O-Ring | EPDM | 2-4 |
| 13 | F40L-95-01 | Retaining Ring | 304SST | 2-4 |