

**Spares List**  
**(F40-1000S)**

<b>Ref.</b>	<b>Part Number</b>	<b>Description</b>	<b>Material</b>	<b>Qty.</b>
1	F40H-21-01	Sealing Plate	ABS	2
2	F40H-58-01/90*5.3	O-Ring	EPDM	4
3	F40H-70-01/28*2.65	O-Ring	EPDM	4-8
4	F40H-98-01	Retaining Ring	304SST	2-4
5	F40H-23-01	Feed/Conc.Port	2205SST/2507SST	2-4
6	F40H-22-01	Bearing Plate	Aluminum Alloy	2
7	F40H-59-01/19*2.65	O-Ring	EPDM	4
8	F40H-95-01	Locking Kit Segment	316LSST	6
9	F40H-09-01	Permeate Port	ABS	2
10	F40H-10-01	Plug	ABS	1
11	F40H-84-01	Securing Screw	304SST	6
12	F40H-61-01	O-Ring	EPDM	4
13	F40H-11-01	Strap	304SST-Rubber	2-3
14	F40H-83-01	Strap Screw	304SST	4-6
15	F40H-03-01	Saddle	Rubber	2-3
16	F40H-85-01	Screw	304SST	2
17	F40H-71-01/17*2.65	O-Ring	EPDM	4
18	F40H-26-01	Adapter	ABS	2